


MDSWIN - Analyse - Software manual- us V 5.0




Constant reading



- Amplituden pressure
- PWA puls wave analyse















VET HDO MONITOR MD PRO 5.0-1/23 us



Parameter setting							PREPARING TO TAKE A READING Monitor Set up:				
Firmware	P-max	P-min	Deflation	Cuff	Position Cuff	Cuff detection	1	100 Nage	Start MDSWIN An	alyse	
Cat preset	175 -300 225	15-45 25	6-15	C1 C1	tail front limb	on	4	V42-Vet_HDO_5000		 Turn on the HDO Wake up HDO press START 	
Dog	175 -300	15-30	6.14	D1	tail	on	4	- Verknüpfung			
preset	225	25	9	D1	front limb	on	4				
Dog	150-300	25-50	03.12.	D2	front limb	on			Connect appropria	, ,	
preset	225	25	6	D2	t	on	act	tivat	the tube into "quick	connector" socket	
Constant	50-225	10-120	time	[′					on rear machine		
preset	100	10 25-75	time 10-20	steps 10-25	1	HDO		еер	Connect the USB	cable or aktivate Bluetooth	
Pulspressure preset	175-275	25-75	10-20	25	1		no 🕅	connection	and check connection	on status	
			L	′	<u> </u>	'					
CONFICT (P5) CO Version MD 5.00.04.42 PS : hold constant the pressure for a time and drop down in steps											
► Wrap t	the cuff aro	ound the te	ail, ensurin	g that the	tube is			MD Parameter		Select cuff typ	
aliged	over the to	op the arte	ery's positie	on					?arameter	Selection to inflate up to mmHg	
•	imb mediar	•	•				4	CuffT C	$1 \vee P-Max$ 225 \vee	Selection to drain to mmHg	
	mb sisteral			I					P-Min 25 ∨	Deflation rate of up mmHg / sec	
		•		-			I			Loop T: Start measuring interval in minutes	
	ccygeal for	for tai	C	C1	D1	D2		Loop t 0	✓ mmHg/s 12 ✓	, o	
Note:	** · Jalk	b	1 (the d				_	Loop n 1	~	Loop N: Numbers of samples per interval	
	iff should be	0,						Loop		SD card:Numbers of stored readings. Delete the readings traschbox	
•	Ũ				prior before	e		Auto		♦ AUTO After the first measurement CO the	
On limit	On limb do not allow animal to place pressure on							Sleep	SD card 11	parameters are optimized for the test subjects. Pmax Pmin mm/s Gain	
										♦ Sleep: modus aktivated or deactivated	
							A State			Battery status	
		Ja.				Real Provide State		Pro Firmware 5.		Start / Stop	